


USER MANUAL



Jamo®

Jamo mini MKII
2.0BT Active

IMPORTANT SAFETY INSTRUCTIONS!







The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.



The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.


1. Read instructions.
2. Retain these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or third prong are provided for your safety. If the provided plug does not fit your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, used caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled, or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.
16. An appliance input coupler is used as the disconnect device - the disconnect device shall remain readily operable.

CARE AND CLEANING




PLACEMENT

Jamo mini MKII



3


SETUP



4

FUNCTION DESCRIPTION

Rear Panel of Master Speaker



1. Increase/decrease volume/input selection (The order of short press switching is "AUX → TV → Bluetooth → USB → AUX →...")

2. TV audio input

3. AUX Input

4. AUX audio input

5. Ultra low frequency line output

6. USB audio input interface, which can be used to connect PC or mobile devices such as phones and tablets to play music. In order to function properly at work, users need to choose the appropriate data cable based on the type of external device to be connected. When connecting to the Windows system when using a PC, only a data cable with a Type-c plug is needed to achieve normal connection. If you want to connect to an Apple computer when using mobile devices such as smart phones and tablets, users need to use a data cable with OTG function so as to achieve normal connection for use.

Reminder: Some early charging cables could not be connected and used for data communication.

7. Power input

Note:

Power On: After plugging the included adaptor into the Power Input (7) port, briefly press the knob (1) to activate the speaker. After power-on, brief press is for input selection; In Bluetooth mode, press and hold the button (5 sec > press time > 3 sec) is for Bluetooth pairing; Press and hold for more than 5 sec is to power off.

Remote Control

1. Press the standby button to enter standby mode.

2. Previous, Play/Pause, Next

3. AUX input selection

4. Bluetooth input

5. Volume buttons

Press " - " to decrease volume.


Press " + " to increase volume.

6. Mute

7. Bluetooth pairing

8. TV input

9. USB input



FUNCTIONS

1. VOLUME/SOURCE Knob

There are 4 functions selectable by the volume/input knob on the rear panel. By turning the knob to the left/right, you can adjust the volume. By short pressing the knob (< 1 second), you can switch among different input sources, in a sequence of “3.5(AUX)→Bluetooth→USB→TV→3.5(AUX)—...”. Press and hold the knob (5 sec > press time > 3 sec) is for Bluetooth pairing. For details of Bluetooth pairing function, please refer to relevant instruction next. Press and hold the knob(more than 5 sec) to turn off the speaker.

2. Power Status Indication

RGB LEDs are used on the front of active speaker to indicate the amplifier status.

Green = AUX input
Purple = TV input
White = USB input
Blue = Bluetooth input (When Bluetooth is not connected, the LED flashes slowly. When the unit is in pairing mode, the LED flashes rapidly. When Bluetooth is connected successfully, the LED will be solid ON.)
Amber color: The flashing Amber LED indicates that the unit has entered the Mute status. The solid ON Amber LED indicates that the unit has entered the Standby status.

FUNCTIONS

Bluetooth

Bluetooth pairing connection and operation:

The Jamo mini MKII speaker supports Bluetooth audio input function and can be connected to Bluetooth devices such as mobile phones and computers to play music. If you are using the Bluetooth function of the Jamo mini MKII speaker for the first time, you need to pair and connect the Jamo mini MKII speaker with your Bluetooth device such as your phone or computer before you can play back and output audio from your device normally.

The specific operation is as follows::

1. Turn on the power of Jamo mini MKII, and wait for 3 seconds.
2. Press the “” button on remote control, or press and hold the “VOLUME/SOURCE” button on the back panel (for about 3 seconds), so as to have the Jamo mini MKII go into Bluetooth pairing mode. Then select the Bluetooth input. Once this has been done, the blue LED will flash rapidly. Otherwise, check if there is any other Bluetooth device already connected to the Jamo mini MKII, and shut it down.
3. Select the Bluetooth function in your smartphone/mobile device, and search for new Bluetooth devices until the Bluetooth device name “Jamo mini MKII” is found. Click it to pair it with your smartphone/mobile device. In case your device requires a pairing code, you can enter “0000” or “1234”.
4. When the Jamo mini MKII is connected to your smartphone/mobile device, the blue LED will be solid ON and stop flashing. Then the pairing is successful.
5. After successful pairing, no manual operation is required for subsequent use. Simply turn on both the speaker and your Bluetooth device, and they will automatically reconnect. If automatic reconnection fails, open your device's Bluetooth settings list, select "Jamo mini MKII," and tap to connect.

Bluetooth Operations

1. Press the “” button on remote control to select the Bluetooth input mode on Jamo mini MKII. Or, press the “VOLUME/SOURCE” button on back panel to access Bluetooth channel.
2. When your smartphone/mobile device is already paired with Jamo mini MKII, open the Bluetooth settings on your device and select “Jamo mini MKII” in your Bluetooth device list. Then your Jamo mini MKII will automatically connect to your device.
3. If your Bluetooth audio device supports the AVRCP protocol, you can use the "Previous Track  / Play/Pause  / Next Track  " buttons on the remote control to remotely control music playback and track selection.

SPECIFICATIONS

Frequency Response [±3] dB [Hz]:	100-20KHz
Sensitivity [2.83V/1m] [dB]:	82±2dB
Impedance:	4 Ohms
Amplifier Type:	CLASS-D
Output Power:	2x35W(RMS)@4ohms THD=10%/2x80W(PEAK)@4ohms THD=10%
Input Voltage:	DC18V/3A
Input Interface:	Bluetooth 5.3 /USB Audio /Jack 3.5/TV
Output Interface:	SUB Out RCAx1 (20-200Hz ±3dB)
Bluetooth:	V5.3, AAC /SBC
Auto Standby Function:	When there is no music signal input for a long while (about 15 minutes), the unit will go to standby automatically.
Standby Power Consumption:	<0.5W, compliant to requirements of EU ERP directives.
Remote Control Function:	Support
Crossover Frequency [Hz]::	2.5kHz
Tweeter:	0.75" (φ19 mm) High-density Neodymium, Micro Horn Waveguide Technology
Woofer:	3" (78x78 mm) High-quality Fiberglass Cone, Phase Plug Technology
System / Cabinet Type:	Vented
Dimensions (WxDxH):	100x135x160mm
Net Weight:	3.30KG (1 pair)



jamo.com

ALL RIGHTS RESERVED
JAMO HOLDING LIMITED
UNIT 2 UG/F BLOCK E WAH LOK
INDUSTRIAL CENTRE 31-35 SHAN
MEI STREET SHA TIN
HK

使用注意事项





⚡ 等边三角形中有箭头闪电标号的图形表示警告使用者在产品内有非绝缘的“危险电压”，可能会对人体造成很大的电击危险。

⚠ 等边三角形中有感叹号的图形表示警告使用者该设备在操作与维护（维修）方面应严格按照所附设备说明书。

- 1) 请详细阅读、保留本使用手册，并遵照本手册的说明进行操作。
- 2) 请注意手册上所有的警示及注意事项。
- 3) 请勿将本产品安装于或靠近会发出热源的地方，如：电热器、电热线圈、火炉等；不能在机箱上放置明火源，如：点亮的蜡烛等。
- 4) 长时间不使用本机时须将插头拔离电源插座，从插座拔出插头时应抓住插头将其拔出。
- 5) 为了完全切断本机电源，电源插头应完全中断机器的电源供应，电源插座必须置于使用者容易接近的地方。
- 6) 请不要靠近水源或有水花溅出的地方使用本产品或任何液体或物品渗入或进入本产品。
- 7) 勿打开后板或改装本机。
- 8) 遇到产品故障或任何有关故障维修的事宜，请咨询认可的维修或服务人员。
- 9) 为避免机体的表面刮伤，我们建议您使用干的软质布料清洁本产品，请勿使用含酒精成份或清洁剂来擦拭机箱以避免损害机体表面的漆质。

CARE AND CLEANING


保养与清洁



PLACEMENT

布置


Jamo mini MKII



13

SETUP


设置



14

功能说明


主箱功放后板



1. 增大/减小音量/输入选择
(短按切换的顺序依次为 “AUX→TV→蓝牙→USB→AUX→...”)
2. TV音频输入
3. 左声道输出(接到副箱)
4. AUX输入选择
5. 超低音线路输出
6. USB音频输入接口，可用于连接PC或手机、平板电脑等移动设备来播放音乐，为了能正常工作，用户需根据将要连接的外部设备类型来选择合适的数据线。当连接windows系统的PC使用时，只需一条带有type-c插头的数据线即可实现正常连接。如果要连接苹果电脑或手机、平板电脑等移动设备使用时，用户则需要使用一条带有OTG功能的数据线，才能正常连接使用。
- 温馨提示：早期的一些充电线由于不能用于数据通讯是无法连接使用的。
7. 电源输入
- 温馨提示：开机：在7. 电源输入处，插入本产品自带的适配器后，需要短按1. 旋钮，音箱才能正式进行工作。开机后短按为输入选择；在蓝牙通道下，长按旋钮(5秒>按压时间>3秒)为蓝牙配对功能；长按超过5秒为关机动作。

遥控器

1. 待机按钮按进入待机模式。
2. 上一曲目、播放/暂停、下一曲目
3. AUX输入选择
4. 蓝牙输入
5. 音量按钮按 “-”，音量减小；
按 “+”，音量增大；
6. 静音
7. 蓝牙配对
8. TV输入选择
9. USB输入选择



1. 音量/模式选择旋钮

后板上的音量/模式选择旋钮具有4种功能，向右/向左旋转为音量加减控制，短按旋钮（按压时间<1秒）为输入模式切换，切换的顺序依次为 “3.5 (AUX)→蓝牙→USB→TV→3.5 (AUX)→…”；长按旋钮 (5秒>按压时间>3秒) 为蓝牙配对功能，关于蓝牙配对功能详见后面相关说明, 长按旋钮（按压时间>5秒）为音箱关机。

2. 电源/状态指示

主箱前面使用了RGB LED灯指示功放的状态：

- 绿色：为AUX输入指示
- 紫色：为TV 输入指示
- 白色：为USB 输入指示
- 蓝色：为蓝牙输入指示，蓝牙未连接，指示灯将缓慢闪烁；蓝牙处于配对状态，指示灯将快速闪烁；蓝牙处于连接状态，指示灯将保持长亮；
- 琥珀色：指示灯闪烁表示产品进入静音状态；指示灯常亮表示产品已进入待机状态。

蓝牙

通过蓝牙配对连接与操作：

Jamo mini MKII音箱支持蓝牙音频输入功能，可连接手机电脑等蓝牙设备播放音乐。
如果您是首次使用Jamo mini MKII音箱的蓝牙功能，则首先要让Jamo mini MKII音箱与你的手机或电脑等蓝牙设备进行配对连接，之后才能正常回放输出您设备上的音频。

具体操作如下：

1. 打开Jamo mini MKII电源，等待3秒钟。
2. 按遥控器上的“”蓝牙配对键，或长按(约3秒)后板上的"音量/模式旋钮"，让Jamo mini MKII进入蓝牙配对状态来选择蓝牙输入模式。一旦您这样做，蓝色指示灯将快速闪烁。如果没有，请检查是否有其他蓝牙设备连接使用Jamo mini MKII并关闭其他蓝牙设备。
3. 选择智能手机/移动设备上的蓝牙功能，然后搜索新功能蓝牙设备，直到名称“Jamo mini MKII”出现在屏幕上。选择“Jamo mini MKII”可与您的智能手机/移动设备配对。如果你的智能手机/手机设备要求输入配对码请输入“0000”或“1234”。
4. 如果配对成功并且Jamo mini MKII已连接到您的智能手机/手机设备，蓝色指示灯将保持亮起并停止闪烁。配对现已完成。
5. 配对连接成功后，下次开机无需再进行上述操作，您只需打开音箱与您的蓝牙设备，二者就可自动回连，如果没能自动回连，你只需打开您设备的蓝牙设备列表，并选择Jamo mini MKII点击连接即可。

操作蓝牙功能

1. 按遥控器上的“”键选择Jamo mini MKII上的蓝牙输入模式或按后板上的“音量/选择模式”按钮进入蓝牙通道。
2. 如果您已经将智能手机/移动设备与Jamo mini MKII配对，请选择打开智能手机/移动设备上的蓝牙设置，然后选择“Jamo mini MKII”出现在您的蓝牙设备列表中。您的Jamo mini MKII将自动连接到您的智能手机/移动设备。
3. 如果您的蓝牙音频设备支持AVRCP协议，您可以通过遥控器上的 “上一曲  /播放/暂停  / 下一曲  ” 键来遥控操作音乐的播放与选曲。

参数规格

频率响应[±3] dB [Hz]:	100–20KHz
灵敏度[2. 83V/1m] [dB]:	82±2dB
阻抗:	4 Ohms
功放类型:	CLASS-D
输出功率:	2×35W (RMS) @4ohms THD=10%/2x80W (PEAK) @4ohms THD=10%
输入电压:	DC18V/3A
输入接口:	Bluetooth 5.3 /USB Audio /Jack 3.5/TV
输出接口:	SUB out RCAx1 (20–200Hz ±3dB)
蓝 牙:	V5. 3, AAC /SBC
自动待机功能:	长时间（约15分钟）没有音乐信号输入将自动待机
待机功耗:	<0. 5W 符合欧盟ERP指令的标准要求
遥控功能:	支持
分频点 [Hz]::	2. 5kHz
高频喇叭:	0. 75" (ϕ 19 mm) 高密度钹铁棚 微型号角扩散技术
低频喇叭:	3" (78x78mm) 高品质玻纤盆 相位塞技术
系统/箱体类型:	倒相箱
尺寸 (WxDxH) :	100x135x160mm
净重:	3. 30KG (1对)



jamo.com

ALL RIGHTS RESERVED
JAMO HOLDING LIMITED
UNIT 2 UG/F BLOCK E WAH LOK
INDUSTRIAL CENTRE 31-35 SHAN
MEI STREET SHA TIN
HK

使用注意事項





-  等邊三角形中有箭頭閃電標號的圖形表示警告使用者在產品內有非絕緣的“危險電壓，可能會對人體造成很大的電擊危險。
-  等邊三角形中有感嘆號的圖形表示警告使用者該設備在操作與維護（維修）方面應嚴格按照所附設備說明書。

- 1) 請詳細閱讀、保留本使用手冊，並遵照本手冊的說明進行操作。
- 2) 請注意手冊上所有的警示及注意事項。
- 3) 請勿將本產品安裝於或靠近會發出熱源的地方，如：電熱器、電熱線圈、火爐等； 不能在主機殼上放置明火源，如：點亮的蠟燭等。
- 4) 長時間不使用本機時須將插頭拔離電源插座，從插座拔出插頭時應抓住插頭將其拔出。
- 5) 為了完全切斷本機電源，電源插頭應完全中斷機器的電源供應，電源插座必須置於使用者容易接近的地方。
- 6) 請不要靠近水源或有水花濺出的地方使用本產品或任何液體或物品滲入或進入本產品。
- 7) 勿打開後板或改裝本機。
- 8) 遇到產品故障或任何有關故障維修的事宜，請諮詢認可的維修或服務人員。
- 9) 為避免機體的表面刮傷，我們建議您使用幹的軟質布料清潔本產品請勿使用含酒精成份或清潔劑來擦拭主機殼以避免損害機體表面的漆質。
- 10) 請不要讓兒童使用遙控器或將遙控器放置於兒童可以拿到的地方，不當的處置電池可能會引起火災或化學性腐蝕，請勿將電池直接進行充電、折開、加熱或改裝本機。 置於高熱（攝氏100度）的地方。

CARE AND CLEANING


保養與清潔



PLACEMENT

佈置


Jamo mini MKII



23

SETUP


設定



24

功能說明

主箱功放後板




1. 增大/减小音量/輸入選擇（短按切換的順序依次為 “AUX→TV→藍牙→USB→AUX→…”）
2. TV音訊輸入
3. 左聲道輸出（接到副箱）
4. AUX輸入選擇
5. 超低音線路輸出
6. USB音訊輸入介面，可用於連接PC或手機、平板電腦等移動設備來播放音樂，為了能正常工作，用戶需根據將要連接的外部設備類型來選擇合適的數據線。當連接windows系統的PC使用時，只需一條帶有type-c插頭的數據線即可實現正常連接。如果要連接蘋果電腦或手機、平板電腦等移動設備使用時，用戶則需要使用一條帶有OTG功能的數據線，才能正常連接使用。
- 溫馨提示：早期的一些充電線由於不能用於數據通訊是無法連接使用的。
7. 電源輸入

溫馨提示：開機：在7. 電源輸入處，插入本產品自帶的轉接器後，需要短按1. 旋鈕，音箱才能正式進行工作。開機後短按為輸入選擇；在藍牙通道下，長按旋鈕（5秒>按壓時間>3秒）為藍牙配對功能；長按超過5秒為關機動作。

遙控器

1. 待機按鈕按進入待機模式。
2. 上一曲目、播放/暫停、下一曲目
3. AUX輸入選擇
4. 藍牙輸入
5. 音量按鈕按 “-” ，音量减小；按 “+” ，音量增大；
6. 靜音
7. 藍牙配對
8. TV輸入選擇
9. USB輸入選擇



功能說明

1. 音量/模式選擇旋鈕

後板上的音量/模式選擇旋鈕具有4種功能，向右/向左旋轉為音量加減控制，短按旋鈕（按壓時間< 1秒）為輸入模式切換，切換的順序依次為“3.5（AUX）→藍牙→USB→TV→3.5（AUX）→…”；長按旋鈕（5秒>按壓時間>3秒）為藍牙配對功能，關於藍牙配對功能詳見後面相關說明，長按旋鈕（按壓時間>5秒）為音箱關機。

2. 電源/狀態指示

主箱前面使用了RGB LED燈指示功放的狀態：

綠色：為AUX輸入指示

紫色：為TV輸入指示

白色：為USB輸入指示

藍色：為藍牙輸入指示，藍牙未連接，指示燈將緩慢閃爍；藍牙處於配對狀態，指示燈將快速閃爍；藍牙處於連接狀態，指示燈將保持長亮；

琥珀色：指示燈閃爍表示產品進入靜音狀態；指示燈常亮表示產品已進入待機狀態。

功能說明

藍牙

通過藍牙配對連接與操作：

Jamo mini MKII音箱支持藍牙音訊輸入功能，可連接手機電腦等藍牙設備播放音樂。

如果您是首次使用Jamo mini MKII音箱的藍牙功能，則首先要讓Jamo mini MKII音箱與你的手機或電腦等藍牙設備進行配對連接，之後才能正常重播輸出您設備上的音訊。

具體操作如下：

1. 打開Jamo mini MKII電源，等待3秒鐘。
2. 按遙控器上的“”藍牙配對鍵，或長按（約3秒）後板上的“音量/模式旋鈕”，讓Jamo mini MKII進入藍牙配對狀態來選擇藍牙輸入模式。一旦您這樣做，藍色指示燈將快速閃爍。如果沒有，請檢查是否有其他藍牙設備連接使用Jamo mini MKII並關閉其他藍牙設備。
3. 選擇智能手機/移動設備上的藍牙功能，然後蒐索新功能藍牙設備，直到名稱“Jamo mini MKII”出現在屏幕上。選擇“Jamo mini MKII”可與您的智能手機/移動設備配對。如果你的智能手機/手機設備要求輸入配對碼請輸入“0000”或“1234”。
4. 如果配對成功並且Jamo mini MKII已連接到您的智能手機/手機設備，藍色指示燈將保持亮起並停止閃爍。配對現已完成。
5. 配對連接成功後，下次開機無需再進行上述操作，您只需打開音箱與您的藍牙設備，二者就可自動回連，如果沒能自動回連，你只需打開您設備的藍牙設備清單，並選擇Jamo mini MKII點擊連接即可。

操作藍牙功能

1. 按遙控器上的“”鍵選擇Jamo mini MKII上的藍牙輸入模式或按後板上的“音量/選擇模式”按鈕進入藍牙通道。
2. 如果您已經將智能手機/移動設備與Jamo mini MKII配對，請選擇打開智能手機/移動設備上的藍牙設定，然後選擇“Jamo mini MKII”出現在您的藍牙設備清單中。您的Jamo mini MKII將自動連接到您的智能手機/移動設備。
3. 如果您的藍牙音訊設備支持AVRCP協定，您可以通過遙控器上的“上一曲  /播放/暫停  /下一曲  ”鍵來遙控操作音樂的播放與選曲。。

參數規格

頻率回應[±3] dB [Hz] :	100-20KHz
靈敏度[2. 83V/1m] [dB] :	82±2dB
阻抗:	4 Ohms
功放類型:	CLASS-D
輸出功率:	2x35W (RMS) @4ohms THD=10%/2x80W (PEAK) @4ohms THD=10%
輸入電壓:	DC18V/3A
輸入介面:	Bluetooth 5.3 /USB Audio /Jack 3.5/TV
輸出介面:	SUB out RCAx1 (20-200Hz ±3dB)
藍牙:	V5.3, AAC /SBC
自動待機功能:	長時間（約15分鐘）沒有音樂訊號輸入將自動待機
待機功耗:	<0.5W 符合歐盟ERP指令的標準要求
遙控功能:	支持
分頻點[Hz]::	2.5kHz
高頻喇叭:	0.75" (φ 19 mm) 高密度鈹鐵硼 微型號角擴散技术
低頻喇叭:	3" (78x78mm) 高品質玻纖盆 相位塞技术
系統/箱體類型:	倒相箱
尺寸(WxDxH) :	100x135x160mm
淨重:	3.30KG (1對)



jamo.com

ALL RIGHTS RESERVED
JAMO HOLDING LIMITED
UNIT 2 UG/F BLOCK E WAH LOK
INDUSTRIAL CENTRE 31-35 SHAN
MEI STREET SHA TIN
HK